

USER GUIDES

Manuals, tutorials & Product Information



Orzly Portable Powerbank

Getting started with the Powerbank

www.orzly.com



@orzly_accessories



Orzly



Orzly Accessories



@orzlytweets



Orzly

Orzly Portable Powerbank

Getting started with the Powerbank



Please note: in order to charge the power bank safely, please use the Micro USB cable enclosed in the box.

Usable Range

The Orzly Power Bank is suitable for most electronic products with a standard 3.6/3.7 Voltage. This makes it compatible with most mobile phones, tablets, hand held games consoles, E-books and a variety of other devices.

Portable Power Bank to Charge your device

Using the USB charging cable included with your device, connect the USB nib to the Orzly Power Bank and the other end to your device. Once connected, the Power Bank will automatically begin to charge your device. Once fully charged please remove the connection between your device and the Power Bank. Once the charging cable has been disconnected, the Power Bank will automatically power off in approximately 15 seconds.

Charging your Power Bank

Included in the box is a Micro USB charging cable. This can be connected to a variety of suitable power sources that have a USB port such as AC Chargers, computers or car chargers. The Micro USB nib is connected to the Power Bank and the USB nib is connected to the power source. Once connected, the Power Bank will automatically begin to charge. Whilst charging the LED Lights will flash sequentially until the Power Bank is fully charged. Once fully charged all the LED lights will remain on.

It is recommended to allow the Orzly Power Bank to fully charge before removing it from the power source. Over charging the Power Bank can result in lifetime of the battery being reduced.

Maintenance and Repair:

1. Keep the Power Bank away from hot surfaces or environments of extreme heat.
2. If accidentally dropped or damaged, do not use the Power Bank if there are cracks, corrosion or deformation on the surface of the charger.
3. Do not dismantle or attempt to remove any components from the Power Bank.
4. Keep the Power bank dry and away from any liquids.